LINE #	ТҮРЕ	DESCRIPTION
1	DAMAGE	INFORMATION LABELS
2	DAMAGE	Emission label 2.4 Liter
3	DAMAGE	FRONT BUMPER & GRILLE
4	DAMAGE	O/H front bumper
5	DAMAGE	Bumper cover
6	DAMAGE	Add for Clear Coat
7	DAMAGE	Sight shield
8	DAMAGE	Energy absorber
9	DAMAGE	Impact bar w/o adaptive cruise
10	DAMAGE	Grille assy w/o sport bumper, w/o adapti

11	DAMAGE	FRONT LAMPS
12	DAMAGE	LT Headlamp assy
13	DAMAGE	Aim headlamps
14	DAMAGE	RT Headlamp assy
15	DAMAGE	RADIATOR SUPPORT
16	DAMAGE	Radiator support
17	DAMAGE	Evacuate & recharge
18	DAMAGE	COOLING
19	DAMAGE	Radiator assy
20	DAMAGE	AIR CONDITIONER & HEATER
21	DAMAGE	Condenser 2.4 liter

22	DAMAGE	LT Air guide w/o sport bumper 2.4 liter
23	DAMAGE	HOOD
24	DAMAGE	Hood
25	DAMAGE	Add for Clear Coat
26	DAMAGE	Add for Underside(Complete)
27	DAMAGE	Add for Clear Coat
28	DAMAGE	RT Hinge
29	DAMAGE	Add for Clear Coat
30	DAMAGE	LT Hinge
31	DAMAGE	Add for Clear Coat
32	DAMAGE	Latch

33	DAMAGE	FENDER
34	DAMAGE	RT Fender
35	DAMAGE	LT Fender
36	DAMAGE	Overlap Major Adj. Panel
37	DAMAGE	Add for Clear Coat
38	DAMAGE	Add for Edging
39	DAMAGE	Add for Clear Coat
40	DAMAGE	RT Fender liner w/o sport bumper
41	DAMAGE	LT Fender liner w/o sport bumper
42	DAMAGE	RT Trim molding
43	DAMAGE	LT Trim molding

44	DAMAGE	RT Corner trim w/o chrome
45	DAMAGE	LT Corner trim w/o chrome
46	DAMAGE	LT Apron assy
47	DAMAGE	LT Apron panel
48	DAMAGE	RT W/shield post
49	DAMAGE	Add for Clear Coat
50	DAMAGE	ELECTRICAL
51	DAMAGE	Battery 80 amp
52	DAMAGE	Battery tray 2.4 liter
53	DAMAGE	Wire harness 2.4 liter, w/o HID headlamp
54	DAMAGE	RESTRAINT SYSTEMS

55	DAMAGE	Driver air bag w/o sport pkg
56	DAMAGE	Psngr air bag
57	DAMAGE	Knee air bag
58	DAMAGE	Clockspring w/o strng whl heat
59	DAMAGE	Diagnostic unit
60	DAMAGE	LT Ft impact sensor
61	DAMAGE	RT Belt & retractor black
62	DAMAGE	LT Belt & retractor black
63	DAMAGE	FRONT DOOR
64	DAMAGE	LT Door shell (HSS)
65	DAMAGE	Overlap Major Adj. Panel

66 DAMAGE Add for Clear Coat  67 DAMAGE LT Belt molding  68 DAMAGE LT Mirror assy w/o blind spot w/o turn I  69 DAMAGE LT Handle, outside primed  70 DAMAGE LT R&I trim panel  71 DAMAGE Flex additive  72 DAMAGE Color sand and buff  73 DAMAGE Overspray Mask Off  74 DAMAGE Mask Jambs  75 DAMAGE Corrosion protection primer  76 DAMAGE Hazardous waste removal			
DAMAGE LT Mirror assy w/o blind spot w/o turn l  DAMAGE LT Handle, outside primed  LT R&I trim panel  DAMAGE Flex additive  DAMAGE Color sand and buff  DAMAGE Overspray Mask Off  AMAGE Mask Jambs  DAMAGE Corrosion protection primer	66	DAMAGE	Add for Clear Coat
69 DAMAGE LT Handle, outside primed  70 DAMAGE LT R&I trim panel  71 DAMAGE Flex additive  72 DAMAGE Color sand and buff  73 DAMAGE Overspray Mask Off  74 DAMAGE Mask Jambs  75 DAMAGE Corrosion protection primer	67	DAMAGE	LT Belt molding
70 DAMAGE LT R&I trim panel  71 DAMAGE Flex additive  72 DAMAGE Color sand and buff  73 DAMAGE Overspray Mask Off  74 DAMAGE Mask Jambs  75 DAMAGE Corrosion protection primer	68	DAMAGE	LT Mirror assy w/o blind spot w/o turn l
71 DAMAGE Flex additive  72 DAMAGE Color sand and buff  73 DAMAGE Overspray Mask Off  74 DAMAGE Mask Jambs  75 DAMAGE Corrosion protection primer	69	DAMAGE	LT Handle, outside primed
72 DAMAGE Color sand and buff  73 DAMAGE Overspray Mask Off  74 DAMAGE Mask Jambs  75 DAMAGE Corrosion protection primer	70	DAMAGE	LT R&I trim panel
73 DAMAGE Overspray Mask Off  74 DAMAGE Mask Jambs  75 DAMAGE Corrosion protection primer	71	DAMAGE	Flex additive
74 DAMAGE Mask Jambs  75 DAMAGE Corrosion protection primer	72	DAMAGE	Color sand and buff
75 DAMAGE Corrosion protection primer	73	DAMAGE	Overspray Mask Off
	74	DAMAGE	Mask Jambs
76 DAMAGE Hazardous waste removal	75	DAMAGE	Corrosion protection primer
	76	DAMAGE	Hazardous waste removal

77	DAMAGE	Towing
78	DAMAGE	A/M Coolant